

Instructions:

- Print out this page, preferably on thick paper or with Carboard backing. Verify the 2.5" wheel bore Measurement with ruler.
- Cut along blue dashed line
- Insert the area marked "insert into wheel bore" into Bore of the wheel. Check for caliper clearance.

